

HANDLER

60U DUST COLLECTOR

The 60U dust collector is designed to provide suction to two 3" work positions, simultaneously. Powered by a ball bearing, capacitor start, industrially rated suction motor, the 60U contains a suction capacity of 400 cfm through two suction inlets provided.

Dust and grindings are cleaned from the air intakes by 14 shakeable cloth filter bags which effectively entrap up to 0.5 micron particles and larger. Manufactured to fit under existing work benches or new installations, its compact size delivers central system suction power. Finished in a durable, baked coating.



Unit Dimensions: 16"W x 14" D x 22" H

- Powerful 400 CFM suction through two inlets .
- Filter Area - 14 shakeable filter bags, 16 sq. ft. filter area.
- Cleaning - External foot shaker, internal dust tray.
- Available with polyester bags for use with aluminum oxide, at additional cost.

60U/S SILENCER



A necessary optional accessory for the 60U Dust Collector, The 60 U/S silencer mounts on top of the 60U and lowers the airflow noise level approximately 20%-25%. Constructed of sheet steel and lined with acoustical foam to reduce noise level of 60U. A must for quiet offices and labs.



**MADE IN
THE USA**

HANDLER

MANUFACTURING CO., INC.

OVER EIGHTY YEARS OF QUALITY MANUFACTURING AND SERVICE...

612 NORTH AVENUE EAST, WESTFIELD, N.J. 07090

Ph: (908) 233-7796 Fax: (908) 233-7340 • 800-27-HANDL • E-Mail: info@handlermfg.com • web site: www.handlermfg.com

Sold Through Distributors Only

